



General SciDome System Cleaning and Maintenance

- Dust all rack and cabinet surfaces with a Swiffer® type duster to prevent dirt build up. Avoid using liquid spray on devices or equipment.
- The Computer Filters are located in the removable front metal grill and can be cleaned with a low suction vacuum or rinsed with water and thoroughly dried.
Spare filters are provided in the original computer box.

CAUTION: Handle filter with care to prevent tearing.

- Use the lens cleaning kit for the projector fisheye lens or camera lens only. Refer to the separate lens cleaning instruction document.
Do not clean any other surfaces with the items in the kit.
- Projector Lamp replacement requires access to the lamp door(s). Refer to the projector manual for specific details based on the model. Be careful not to disturb the projector position which may alter the alignment.
 - Note: Center Mounted Projector Stands require cover removal in order to gain access to the lamp door(s).

CAUTION:

Spitz does not recommend using third party lamps, bulbs or assemblies.

Always install NEW genuine manufactured lamp and housing assemblies.

- The Projector(s) outside case can be cleaned. Refer to the projector manual for detailed information on cleaning or maintenance for the specific model. Use a Swiffer® type duster or low suction vacuum with brush to clean external surfaces. Important to clean any intake or exhaust grills and filter screens. Some projectors have no removable filters. Therefore, care must be exercised to prevent tears or holes while cleaning. Be careful not to disturb the projector position which may alter the alignment.
- **If there are any questions or concerns about the devices or equipment, contact Customer Support:**
 - **800 639-1482**
 - **customersupport@spitzinc.com**

SPITZ, INC

P.O. Box 198
700 Brandywine Dr.
Chadds Ford, PA 19317
U S A

Tel: 610.459.5200
Fax: 610.459.3830

Customer Service:

800-639-1482
customersupport@spitzinc.com

www.spitzinc.com